

Tonearm counterweight installation

1. Mark top side of tonearm cable plug and removed cable plug from amplifier
2. Remove tonearm cable by loosening clamps and grounding screws
3. Remove tonearm retaining screw
4. Remove tonearm by lifting straight up
5. Remove stock adjustment spring located within the tonearm
6. Place adhesive drill guide on back of tonearm aligning with the bottom edge
7. Drill 3/16" hole using center of drill guide
8. Install tonearm counterweight as shown
9. Re-install tonearm and cable
10. Adjust counterweight location to achieve desired tonearm weight
11. Tighten nut against counterweight to secure

